

# OACIS

Open Architecture Control Integrated System

## How To Configure

Version 05.00.02



[www.atainc.com](http://www.atainc.com)

[ata@atainc.com](mailto:ata@atainc.com)


All Rights Reserved



## CONTENTS


<b>I. SYSTEM CONFIGURATION.....</b>	<b>3</b>
A. GENERAL.....	3
B. AXES .....	3
C. Analog Inputs.....	5
D. RS232 Ports .....	6
E. Encoder Inputs.....	13
<b>II. LOCAL CONFIGURATION .....</b>	<b>14</b>
<b>III. CHANGE OACIS IP ADDRESS .....</b>	<b>15</b>
A. Using LAN Communication .....	15
<b>IV. ADMIN CONFIGURATION.....</b>	<b>16</b>
A. User Configuration.....	16
<b>V. Debug.....</b>	<b>22</b>
A. ADMIN STATUS .....	22
B. SERIAL COM.....	22
C. UDP COM.....	23
D. DATA MANAGER.....	23
E. TOOL .....	24
<b>APPENDIX #2: LAN (UDP) COMMUNICATION EXAMPLE .....</b>	<b>30</b>
<b>APPENDIX #3: OMRON G SERIES SERVO DRIVE SETTING .....</b>	<b>31</b>
<b>APPENDIX #4: OMRON G5 SERIES SERVO DRIVE SETTING .....</b>	<b>34</b>
<b>APPENDIX #5: MITSUBISHI MR-J3-A SERIES SERVO DRIVE SETTING.....</b>	<b>36</b>
<b>APPENDIX #6: MITSUBISHI MR-J4-A SERIES SERVO DRIVE SETTING.....</b>	<b>37</b>
<b>APPENDIX #7: PANASONIC MINAS A5-SERIES SERVO DRIVE SETTING ..</b>	<b>38</b>
<b>APPENDIX #8: PANASONIC MINAS A6-SERIES SERVO DRIVE SETTING ..</b>	<b>41</b>
<b>REVISION .....</b>	<b>43</b>

I. SYSTEM CONFIGURATION



HOW TO CONFIGURE

- **OPEN:** Open configuration files (\*.oacx) from your PC. You can also open previous versions (\*.oac).



- **OPEN (FROM OACIS):** Check the box to load the configuration file from OACIS and display it on the screen.
- **SAVE:** Upload the updated configuration to OACIS while simultaneously saving it to your local PC.
- **SAVE (ONLY TO PC):** Save the updated configuration to the local PC only.
- **SET AS OFFLINE CONFIG:** Enable offline mode for the current configuration. You can edit OACIS or PC system settings while offline.

A. GENERAL

NAME	None
DATE and TIME	000000/000000
VERSION	V01.0

- **NAME:** The name of current configuration.
- **DATE and TIME:** It is automatically created
- **VERSION:** Enter the configuration version in the format 'V01.0'

B. AXES

: It is strongly recommended that users do not modify these parameters. If any issues arise, please consult ATAINC first

The screenshot displays the 'AXES' configuration page. On the left, a sidebar contains navigation icons for 'GENERAL', 'AXES', 'ANALOG INPUTS', 'RS232', and 'ENCODER INPUTS'. The main area is divided into two columns: 'AXIS #1' (Enabled) and 'AXIS #2' (Disabled). Each axis configuration includes a dropdown for 'Axis Type' (set to 'PRESS (kN)'), a 'Default Analog Input Ch.' dropdown (set to 'ANALOG INPUT Ch. 1' for Axis #1 and 'ANALOG INPUT Ch. 2' for Axis #2), and a 'Spindle Direction' dropdown (set to 'LEFT'). Below these are various numerical input fields for limits and gains, such as 'Positive Position Limit' (9000.0000), 'Negative Position Limit' (-9000.0000), 'Positive Load Limit' (9000.0000), 'Negative Load Limit' (-9000.0000), 'Speed Limit' (9000.0000), 'Acceleration Limit' (9000.0000), 'P Gain' (0.0000), 'I Gain' (0.0000), 'D Gain' (0.0000), 'Move to Home Speed' (0.0000), 'Move to Home Acceleration' (0.0000), 'Move to Home Load Limit' (0.0000), 'Basic Displacement' (0000000), 'Pulse Per Basic Displacement' (0000000), and 'Power Ratio' (0.0000).

- **Enabled & Disabled:** Users can enable or disable each axis. Ensure these settings match the physical system integration
- **Axis Type:**
  - **[PRESS (kN)]:** This servo press features linear movement with force measured in 'kN'. It includes signals for Home, Positive Limit, and Negative Limit. The default AI channel must also be set to 'kN'.
  - **[NUT RUNNER #1 (With Only Home)]:** This servo spindle features angular movement with torque measured in 'Nm'. It includes the Home signal only.
  - **[NUT RUNNER #2 (Without Home and Limits)]:** This servo spindle features angular movement with torque measured in 'Nm'. It does not include Home or Limit signals; therefore, triggering the 'Homing' function will set the current position as the new Home
  - **[NUT RUNNER #3 (With Only Limits)]:** This servo spindle features angular movement with torque measured in 'Nm'. It does not have a dedicated Home signal but includes Positive and Negative Limit signals. The system finds both limits and automatically moves to the center position to define the Home position.
  - **[MICRO PRESS (kN)]:** This is a specialized short-stroke Servo Press. The force unit is 'kN', and the default AI channel must also be set to 'kN'.
  - **[NUT RUNNER #4 (With Home and Limits)]:** This servo spindle features angular movement with torque measured in 'Nm'. This servo spindle is equipped with Home, Negative Limit, and Positive Limit sensors.
  - **[PRESS (N)]:** This servo press features linear movement with force measured in 'N'. The default AI channel must also be set to 'N'.
  - **[PRESS (kgf)]:** This servo press features linear movement with force measured in 'kgf'. The default AI channel must also be set to 'kgf'.
  - **[PRESS (tnf / kgfx10^3)]:** This servo press features linear movement with force measured in 'tnf'. The default AI channel must also be set to 'tnf'.

- **Default Analog Input Ch.**
  - Select one of the available analog signals.
  - The selected channel will be applied to all load parameter settings by default.
- **Spindle Direction**
  - [Right] or [Left]
  - Set the servo motor direction to align with positive spindle movement.
- **Positive Load Direction**
  - [+] or [-]
  - Analog Input direction for positive axis movement.
- **Positive Position Limit**
  - [mm] or [deg]
  - The maximum allowable position in the positive direction
- **Negative Position Limit**
  - [mm] or [deg]
  - The minimum allowable position in the positive direction
- **Positive Load Limit**
  - The maximum allowable load
- **Negative Load Limit**
  - The minimum allowable load
- **Speed Limit**
  - The maximum allowable speed
- **Acceleration Limit**
  - The maximum allowable acceleration
- **P, I, D gains**
  - Axis control gains.
- **Move to Home Speed**
  - Homing speed
- **Move to Home Acc.**
  - Homing acceleration
- **Move to Home Load Limit**
  - It is defined as the absolute value of the maximum or minimum allowable load during homing.
- **Basic Displacement, Pulse Per Basic Displacement and Power Ratio**
  - Parameters for axis motion control.

### C. Analog Inputs

The screenshot shows the 'ANALOG INPUTS' configuration window. It includes a sidebar with 'GENERAL', 'AXES', and 'ANALOG INPUTS' tabs. The main area shows a configuration for 'Analog Input Ch. #1'. A blue toggle switch is labeled 'Enabled'. Below it, the configuration parameters are: Unit: kN, Signal Type: -10V ~ +10V, Min. Range: -9000.0000, Max. Range: 9000.0000, and Sampling Rate: 50.


- **Unit**
  - [kN], [Nm], [Bar], [Mpa], [l/m], [RPM], [mm], [N], [kgf], [Generic].or [tnf]
  - Select the signal type that matches the physical input (Load, Torque, Pressure, Flow, or Speed).
- **Signal Type**
  - [4 ~ 20mA] or [+/- 10V]
  - Select the appropriate option based on the signal type.
- **Min Range**
  - Value at Minimum Signal.
- **Max Range**
  - Value at Maximum Signal.
- **Sampling Rate**
  - 0 ~
  - Sampling rate for raw data acquisition. It functions as signal averaging; setting it to '0' means no

averaging.

- **Example #1**
  - Selected Signal Type: [4 ~ 20mA] / Min Range: -110 / Max Range: +100
  - 4mA -> -110 / 20mA -> +100
- **Example #2**
  - Selected Signal Type: [+/- 10V] / Min Range: -90 / Max Range: +120
  - -10V -> -90 / +10V -> +120

#### D. RS232 Ports

- **Baud Rate, Parity, Stop Bit and Data Bit** must be set properly.
- **Linked DO Ch.:** This DO signal stays ON for 1 second upon successful data acquisition by OACIS.
- **Time Limit [x100ms]:** It specifies the timeout for OACIS data reception. The input value is multiplied by 100 ms (e.g., an input of 5 equals 500 ms). The default setting is 2 (200 ms).
  - The maximum data capacity OACIS can receive from external devices varies by baud rate. At 9,600 bps, OACIS requires approximately 1 ms per symbol. Therefore, a time limit of 1 (100 ms) is sufficient to receive 20 symbols, as the total processing time is roughly 20 ms
- **[Scan In] mode or [Data Out] mode** can be selected.



- Both axes cannot be set to [Scan In] mode simultaneously.
- [Data Out] mode is supported for both axes.

##### 1. [Scan In] Mode

: This function saves scanned information into the test results. It supports barcode scanners and other devices capable of transmitting serial numbers. Users can choose between [Use Format] and [Do Not Use Format] for data processing.

###### a. [Use Format]: Use Format (for Scan-In Mode)

: The 'Use Format' option allows data to be saved according to your custom configuration.

- **Total Length (bytes):** Total length (bytes) to be received.
- **Starting Byte Index:** It is a zero-based index. Setting it to 2 will cause OACIS to start saving from the 3rd byte of the received data.
- **Length (bytes):** Length of bytes to be saved in the cycle results. Max Allowable "LENGTH" is 59.

- **Start Delimiter (0x):** The byte value (decimal) used to identify the start of the data frame. A value between 0x00 and 0x7F can be entered, and the corresponding hexadecimal representation is displayed on the right.
- **End Delimiter (0x):** The byte value (decimal) used to identify the end of the data frame. A value between 0x00 and 0x7F can be entered, . and the corresponding hexadecimal representation is displayed on the right.

**Example #1) Use “START DELIMITER” / Not Use “END DELIMITER”**

The screenshot shows the RS232 #1 configuration interface. At the top, there is a 'Scan In' toggle which is turned on. Below it, various settings are displayed in a list format:

- Baud Rate: 9600
- Parity: None
- Stop Bit: 1
- Data Bits: 8
- Linked DO Ch.: 01
- Time Limit (x100 ms): 01
- Use Format (for Scan-In Mode)
- Total Length (bytes): 10
- Starting Byte Index: 02
- Length (bytes): 06
- Start Delimiter (0x): 65 (hex: 0x41)
- End Delimiter (0x): 00 (hex: 0x00 : Not Use)
- Point Type: Fixed
- Point Position: 4
- Request Required
- Data Out Mode: DAA (value: 0)

HOW TO CONFIGURE

- Configuration Setting
  - Starting Byte No.: 2
  - Length: 6
  - Total Length: 10
  - Start Delimiter: 65 (base-10) -> 0x41 (base-16) > A (ASCII)
  - End Delimiter: Not Use(0x00)

➤ Saved Data per Scanned Information

No.	Data to the OACIS	Received Data	Saved Data	Linked DO
1	A123456789	A123456789	234567	ON
2	CBA123456789	A123456789	234567	ON
3	CBA12345678	None	None	OFF
4	CBA1234567890123	A123456789	234567	ON
5	CBA123456789A0123	A123456789	234567	ON
6	CBA123456789A0123456789	A012345678	123456	ON
7	CBA12345678A90123	None	None	OFF

- Comments:
  - **No. 1:** The total length is 10 bytes, starting from the delimiter 'A'. With the 'Starting Byte' set to 2 and 'Length' to 6, OACIS saves '234567'—the 6 bytes of data following the initial 2-byte offset..
  - **No. 3:** Invalid scan: The data length between delimiter 'A' and the last byte '8' is only 9

bytes, which is shorter than the required total length.

- **No. 6:** The last valid data string, 'A012345678', is identified as the received data. With a Starting Byte of 2 and a Length of 6, the system saves '123456'.

**Example #2) Use "START DELIMITER" / Use "END DELIMITER"**

Scan In RS232 #1

Baud Rate: 9600

Parity: None

Stop Bit: 1

Data Bits: 8

Linked DO Ch.: 01

Time Limit (x100 ms): 01

Use Format (for Scan-In Mode)

Total Length (bytes): 00

Starting Byte Index: 02

Length (bytes): 06

Start Delimiter (0x): 65 0x41

End Delimiter (0x): 57 0x39

Point Type: Fixed

Point Position: 4

Request Required

Data Out Mode: DAA 0

- Configuration Setting
  - Starting Byte No.: 2
  - Length: 6
  - Total Length: N/A
  - Start Delimiter: 65 (base-10) -> 0x41 (base-16) > A (ASCII)
  - End Delimiter: 57 (base-10) -> 0x39 (base-16) -> 9 (ASCII)

➤ Saved Data per Scanned Information

No.	Scanned Information	Received Data	Saved Data	Linked DO
1	A123456789	A123456789	234567	ON
2	CBA123456789	A123456789	234567	ON
3	CBA12345678	None	None	OFF
4	CBA1234567890123	A123456789	234567	ON
5	CBA12345678A90123	A12345678A9	234567	ON
6	CBA1234567890A1234569	A1234569	234569	ON
7	CBA123456789012345A69	A69	9	ON
8	CBA1234567890123456A9	A123456789	234567	ON
9	CB1234567890123	None	None	OFF

- Comments:
  - **No. 1:** The received data 'A123456789' contains delimiters 'A' and '9'. With a Starting Byte set to 2 and a Length of 6, OACIS excludes the first 2 bytes and saves '234567'.
  - **No. 3:** Invalid scan: End delimiter is missing.

- **No. 6:** The last valid data, 'A1234569', is identified as the received data. With the Starting Byte set to 2 and Length to 6, '234569' is saved, excluding the first two bytes ('A1').
- **No. 8:** The last entry 'A9' is invalid because the received data must be longer than the Starting Byte index. Consequently, the first valid data, 'A123456789', is selected. OACIS then saves '234567', excluding the first two bytes ('A1').
- **No. 9:** Invalid scan data: Missing start delimiter.

**Example #3) Not Use "START DELIMITER" / Not Use "END DELIMITER"**

HOW TO CONFIGURE

- Configuration Setting
  - Starting Byte No.: 2
  - Length: 6
  - Total Length: 10
  - Start Delimiter: Not Use(0x00)
  - End Delimiter: Not Use(0x00)

➤ Saved Data per Scanned Information

No.	Scanned Information	Received Data	Saved Data	Linked DO
1	A123456789	A123456789	234567	ON
2	CBA123456789	CBA1234567	A12345	ON
3	CBA12345678	CBA1234567	A12345	ON
4	CBA1234567890123456	CBA1234567	A12345	ON
5	CBA1234567890123456789	8901234567	012345	ON
6	CBA123456	None	None	OFF

- Comments:
  - **No. 2:** Scanned data length: 10 bytes. OACIS extracts 6 bytes starting from the 2nd byte. Result: '234567' saved (excluding 'A1').
  - **No. 4:** The first 10 bytes, 'CBA1234567', are selected because the second term, '890123456', has an invalid length of 9 bytes. Consequently, 'A12345' is saved after excluding the prefix 'CB'.

- **No. 5:** The final valid data is '8901234567'; accordingly, OACIS saves '012345'..
- **No. 6:** Invalid data length: The scanned information is 9 bytes, which does not meet the required length of 10.

**Example #4) Not Use “START DELIMITER” / Use “END DELIMITER”**

- Configuration Setting
  - Starting Byte No.: 2
  - Length: 6
  - Total Length: N/A
  - Start Delimiter: Not Use(0x00)
  - End Delimiter: '9'

➤ Saved Data per Scanned Information

No.	Scanned Information	Received Data	Saved Data	Linked DO
1	A123456789	A123456789	234567	ON
2	CBA123456789	CBA123456789	A12345	ON
3	CBA12345678	None	None	OFF
4	CBA123456789012345678	CBA123456789	A12345	ON
5	CBA12345678909	CBA123456789	A12345	ON
6	CBA123456789019	019	9	ON
7	CBA123456789012349	012349	2349	ON

- Comments:
  - **No. 2:** With the end delimiter set to '9', the received data is 'CBA123456789' (from the first byte to the delimiter). Based on a starting position at the 2nd byte and a length of 6, OACIS extracts and saves '234567', excluding the 'A1'.
  - **No. 3:** Invalid scanned data: Missing end delimiter.
  - **No. 5:** The suffix '09' is invalid because the received data length is shorter than the

required starting byte index. Consequently, 'CBA123456789' was identified as the first valid data set, and OACIS saved 'A12345' (excluding the 'CB').

- **No. 7:** The last valid data, '012349', was selected. Based on a starting byte of 2 and a length of 6, OACIS saved '2349', excluding '01'.

b. **[Not Use Format]:**

Not Use Format

- i. The Linked DO blinks whenever OACIS receives scanned data.
- ii. OACIS saves the scanned data along with its test results.
- iii. If the length exceeds 59 bytes, OACIS only saves the first 59 bytes.



## CAUTION

1. All semicolons (;) in the received data are automatically converted to colons (:).
2. Although semicolons (;) can be used as delimiters, they will be converted to colons (:) within the received data..
3. Start and end delimiters cannot be the same, unless they are set to 'Not Use' (0x00).

## 2. [Data Out] Mode

Data Out		RS232 #1	
Baud Rate	9600		
Parity	None		
Stop Bit	1		
Data Bits	8		
Linked DO Ch.	00		
Time Limit (x100 ms)	00		
	<input checked="" type="checkbox"/> Use Format (for Scan-In Mode)		
Total Length (bytes)	10		
Starting Byte Index	02		
Length (bytes)	06		
Start Delimiter (0x)	00	0x00 : Not Use	
End Delimiter (0x)	57	0x39	
Point Type	Floating		
Point Position	1		
	<input checked="" type="checkbox"/> Request Required		
Data Out Mode	DAA	0	

- It is to be used to communicate with external device like PLC.
  - [Not Use Format]
- a. **Starting Byte No:** N/A
  - b. **Length:** Data Transmission Length: If set to 5, OACIS transmits 5 results (Global Variables #1 through #5) along with the scanned data. If no data is scanned, 'None' will be sent as the default value.
  - c. **[Always] or [Request Required]**
    - i. [Always]: Whenever the OACIS complete cycle, it sends out results per the above "Length" setting.
    - ii. [Request Required]: The OACIS sends out results with proper request command. See the Appendix #1 for detailed communication protocol.
  - d. **Total Length:** N/A
  - e. **Linked DO Ch.:** N/A
  - f. **Time Limit [x100ms]:** The elapsed time for OACIS to receive the data. The default (00) is 200 ms.
    - i. You may need to adjust the time limit according to the data to be sent into OACIS. If the baud rate is 9600 and the size of data to receive is 370 symbols, you should input over 4 (400ms). OACIS needs about 1 ms for 1 symbol of input data.
  - g. **Point Type:**
    - i. [Floating] or [Fixed].
    - ii. [Floating]: OACIS returns the results with "Floating Point" format.
    - iii. [Fixed]: OACIS returns the results with "Fixed Point" format.
  - h. **Point Position:**
    - i. It would be one of "1 ~ 8".
    - ii. If you set it as "3". OACIS returns the result with "00000.000" format. If you set it as "6", OACIS returns the result with "00.000000" format.
  - i. **Data Out Mode:** If you set as [Always], you can select "Data Out Mode" one of followings.
    - i. [DAA]: OACIS sends out all test results (see the Appendix #1 for more details)
    - ii. [DAB]: OACIS sends out all test results with Failure Mode and Date information. (see

- the Appendix #1 for more details)
- iii. [D##] + [###]: OACIS sends out the selected four data. If you set [D##] + [001] and OACIS will send out first four data. (see the Appendix #1 for more details)

### E. Encoder Inputs

: You can select Encoder Signal type [TTL] or [Line Receiver] based on physical signal. If you set [TTL Encoder Input #1] as "Use", you can't set [Line Receiver Encoder Input #1] as "Use". One of them gets set as "Not Use" automatically.

The screenshot shows the 'ENCODER INPUTS' configuration window. On the left, there is a sidebar with navigation icons for GENERAL, AXES, ANALOG INPUTS, RS232, and ENCODER INPUTS. The main area is titled 'ENCODER INPUTS' and contains two channels:


- Encoder Input Ch. #1:** Enabled. Unit: mm, Direction: +, Pulse Ratio: 0, Signal Type: LINE DRIVER (selected).
- Encoder Input Ch. #2:** Disabled. Unit: mm, Direction: +, Pulse Ratio: 0, Signal Type: LINE DRIVER (selected).

- **Unit**
  - [mm] or [deg]
  - You need to select one in accordance with the physical signal type (Linear Encoder or Angular Encoder)
- **Direction**
  - [+] or [-]. If you set as [+], when the signal increases the value will be increased.
- **Pulse Ratio**
  - The pulse quantity to be matched with unit displacement (1 deg or 1mm). It is to be set by ATAinc.
- **Type**
  - [TTL] or [LINE RECEIVER] per encoder input channel

## II. LOCAL CONFIGURATION

: You can set several specific local parameters by using “Local Configuration”. Basically it has nothing to do with physical performance of OACIS controller.


Menu Bar -> [CONFIGURATION]-[Local]



- **SYSTEM NAME:**
  - It is used for main screen title.
- **TARGET OACIS IP ADDRESS:**
  - The IP Address of target OACIS that users want to connect.
  - Default OACIS IP Address: 192.168.0.3
- **STATUS UPDATE PERIOD (ms):**
  - If users set it as 20, OACIScom is updating the status every 20ms. It has nothing to do with OACIS' control period.
- **PASSWORD:**
  - Users can set new password.
  - Default Password: "1"
- **AUTO RESET COUNT:**
  - Once enabled, the count resets at the set time


III. CHANGE OACIS IP ADDRESS

: There are two ways to change the OACIS IP Address. You can change the IP Address using LAN or RS232.



A. Using LAN Communication

: Menu Bar -> [TOOL]-[Ethernet Properties]



HOW TO CONFIGURE


- **TARGET OACIS IP ADDRESS:**
  - OACIS default IP Address is “192.168.0.3”.
  - You can input the New IP Address.
    1. “192.168.###.###” is recommended for local area network.
    2. “192.168.0.0” and “192.168.255.255” is normally not allowed
- **TARGET OACIS SUBNET MASK:**
- **TARGET OACIS GATEWAY:**
- **You can change the IP Address by clicking “CHANGE PROPERTIES.” Button.**
  - You may need to change the Target OACIS IP Address of Local Configuration and your PC’s IP Address depending on the new OACIS IP Address.
  - To change the IP Address via LAN communication, you may need to know current IP Address (Your PC should be connected to the target OACIS first). If you forgot the IP Address, you can change the IP Address via RS232 communication.

## IV. ADMIN CONFIGURATION

: It allows you to do “Read System Version Information”, “Test RS232 Communication” and “Set User Configuration”.

Menu Bar -> [CONFIGURATION] - [User]

Password is 1.



### A. User Configuration

: You can set the “USER CONFIGURATION” of the connected OACIS.

#	DESCRIPTION	VALUE
01	Axis #1 Home Position Error Limit	0
02	Axis #2 Home Position Error Limit	0
03	Axis #3 Home Position Error Limit	0
04	Axis #4 Home Position Error Limit	0
05	Axis #1 Position Control Error Limit	0
06	Axis #2 Position Control Error Limit	0
07	Axis #3 Position Control Error Limit	0
08	Axis #4 Position Control Error Limit	0
09	Axis #1 DI Jog Mode Enable (0: Disable / 1:Enable)	0
10	Axis #2 DI Jog Mode Enable (0: Disable / 1:Enable)	0
11	Axis #3 DI Jog Mode Enable (0: Disable / 1:Enable)	0
12	Axis #4 DI Jog Mode Enable (0: Disable / 1:Enable)	0
13	Axis #1 DI Jog Speed	0
14	Axis #2 DI Jog Speed	0
15	Axis #3 DI Jog Speed	0
16	Axis #4 DI Jog Speed	0
17	Axis #1 System Home	0
18	Axis #2 System Home	0
19	Axis #3 System Home	0
20	Axis #4 System Home	0
21	Axis #1 Drive Type (0: OMRON, LS, Panasonic / 1: MITSUBISHI)	0
22	Axis #2 Drive Type (0: OMRON, LS, Panasonic / 1: MITSUBISHI)	0
23	Axis #3 Drive Type (0: OMRON, LS, Panasonic / 1: MITSUBISHI)	0
24	Axis #4 Drive Type (0: OMRON, LS, Panasonic / 1: MITSUBISHI)	0
25	Axis #1 Jog Load Limit	0
26	Axis #2 Jog Load Limit	0
27	Axis #3 Jog Load Limit	0
28	Axis #4 Jog Load Limit	0
29	Axis #1 Position Control 2nd Parameter	0
30	Axis #2 Position Control 2nd Parameter	0
31	Axis #3 Position Control 2nd Parameter	0
32	Axis #4 Position Control 2nd Parameter	0
33	Home Signal Priority	0
34	Stop Option	0
35	Program End Time Delay	0
36	Program Start Mode	0
37	Tare Axes Load After Homing (0:Not Applied/ 1:Only Axis1/ 2:Only Axis2 / 3:Axis1 & Axis2)	0
38	Fieldbus Config (AABB.CCDD: AA:Module Select(00: EIP, ProfNet / 01: CC Link) / BB:Return Axis Info(00:Not Use/01:Use) / CCDD:Reserved)	0
39	Fieldbus Module Config (AABB.CCDD: In the case of CCLink: CC: Node No / DD: Baud Rate)	0
40	Program Execution Time Option	0
41		

- OPEN:** You can read User Configuration from the local PC.
- OPEN (FROM OACIS):** You can read User Configuration from the connected OACIS.
- SAVE:** You can save the updated User Configuration to both OACIS and the local PC.
- SAVE (ONLY TO PC):** You can save the updated User Configuration only to the local PC.
- NAME:** Users can change the name of User Configuration
- PARAMETERS:**
  - **Axis #1 Home Position Error Limit:** It specifies 'Home' and 'Program Home' Position Range. If the Axis is out of the range, OACIS requires homing.
    - Example: If you set 'Program Home' as 50 ('Home Position' should be 0) and you set 'Home Position Error Limit' as 0.2. In this case, OACIS specifies the Home Position range from -0.2 to +0.2 and Program Home Position range from +49.8 to +50.2. If the Axis deviates from the range, OACIS requires homing again.
  - **Axis #2 Home Position Error Limit:** See above.
  - **Axis #3 Home Position Error Limit:** See above.
  - **Axis #4 Home Position Error Limit:** See above.
  - **Axis #1 Position Control Error Limit:** It specifies position control error limit. While OACIS is running, if the deviation between actual position and target position is bigger than this limit, OACIS stop running and shows the proper error code.
  - **Axis #2 Position Control Error Limit:** See above.
  - **Axis #3 Position Control Error Limit:** See above.
  - **Axis #4 Position Control Error Limit:** See above.

- **Axis #1 DI Jog Mode Enable:** If you set it as 1, you can enable the Axis DI Jog Mode. Then, you can move the Axis by turning on the Programmable Digital Input Signal (DI#13 and DI#14). Default value is 0 (Disable). See below table for more details on 'DI Jog Mode'.
- **Axis #2 DI Jog Mode Enable:** See above.
- **Axis #3 DI Jog Mode Enable:** See above.
- **Axis #4 DI Jog Mode Enable:** See above.
- **Axis #1 DI Jog Speed:** If the Axis DI Jog Mode is enabled, you can set the DI Jog Speed here.
- **Axis #2 DI Jog Speed:** See above.
- **Axis #3 DI Jog Speed:** See above.
- **Axis #4 DI Jog Speed:** See above.
- **Axis #1 System Home:** OACIS move all Axes to this position after every "Homing" sequence.
- **Axis #2 System Home:** See above.
- **Axis #3 System Home:** See above.
- **Axis #4 System Home:** See above.
- **Axis #1 Drive Type (0: OMRON, LS / 1: MITSUBISH):** You can configure your Servo Drive Type. "0" means OMRON or LS, "1" means MITSUBISH.
- **Axis #2 Drive Type (0: OMRON, LS / 1: MITSUBISH):** See above.
- **Axis #3 Drive Type (0: OMRON, LS / 1: MITSUBISH):** See above.
- **Axis #4 Drive Type (0: OMRON, LS / 1: MITSUBISH):** See above.
- **Axis #1 Jog Load Limit:** You can set Load Limit of Jog operation.
- **Axis #2 Jog Load Limit:** You can set Load Limit of Jog operation.
- **Axis #3 Jog Load Limit:** You can set Load Limit of Jog operation.
- **Axis #4 Jog Load Limit:** You can set Load Limit of Jog operation.
- **Axis #1 Move to Position Target Tolerance:** It specifies convergence criteria for the target position in the "Move to Position" step.
  - Example: If you set 'Target Position' as 50 and you set 'Move to Position Target Tolerance' as 0.005, Axis #1 moves until it arrives at the target window from 49.995 to 50.005. If you set it as 0, Axis #1 moves until the target position 50.
  - Unless Axis #1 can arrive at the target window even in 10 seconds, OACIS terminate the 'Move to Position' step.
- **Axis #2 Move to Position Target Tolerance:** See above.
- **Axis #3 Move to Position Target Tolerance:** See above.
- **Axis #4 Move to Position Target Tolerance:** See above.
- **Home Signal Priority:** At least one of two, HOME OK and PROGRAM HOME OK should be turned on for OACIS to start a program. If OACIS uses both axis #1 and #2, OACIS normally determines the On/Off status of overall HOME OK and PROGRAM HOME OK via AND operation like examples below.

Axis #1		Axis #2		OACIS	
HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK
O	O	O	X	O	X
O	O	X	O	X	O
X	O	O	O	X	O
X	X	O	O	X	X

However, there is an exception for this rule. If the condition is the same as below, OACIS cannot start a program although both Axis #1 and #2 are in the startable condition.

Axis #1		Axis #2		OACIS	
HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK
O	X	X	O	X	X

X	O	O	X	X	X
---	---	---	---	---	---

In this case, we utilize the Home Signal Priority parameter. If you set the parameter as 0, OACIS follows Axis #1 condition. And if it is 1, it follows Axis #2 one.

Axis #1		Axis #2		OACIS			
HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK	0 (Default)		1	
				HOME OK	PROGRAM HOME OK	HOME OK	PROGRAM HOME OK
O	X	X	O	O	X	X	O
X	O	O	X	X	O	O	X

- **Stop Option:** OACIS has “Stop” signal. It is used to stop OACIS running for a while and resume it. But do not use this option as its safety circuit. Most of press machines are supposed to be equipped with their own safety circuits. This is not a hardware stop but only a software stop.
  - **0(default):** OACIS stops after on-going step is completely done and resumes at the next step.
  - **1:** OACIS stops on the spot. When it resumes, it restarts the on-going step. See the timing sequence manual.
  - **2:** It is the same as option 1 except that it restarts after resetting motor drive. For example, when you use program stop instead of E-stop in STO safety circuit, we recommend this option to use.
- **Program Execution Time:** OACIS can adjust program resume time with this option. It is normally used when the execution time is too short to save GVs Information after program end. If the execution time is shorter than GV saving time, you need to set program execution time as more than the saving time. The unit is a second. For example,
  - When setting 0 as program execution time option, it means minimum time from program start to resume.
  - When setting 1 as the option, it means delay time from program end to resume.
- **Program Start Mode:** OACIS has two means of starting a program. One is Handshake type that is controlled by external devices like PLC. The other is Pulse type that can be triggered by a simple input device like push button. Pulse type comes in handy when there is no external controller except for OACIS.
  - **0 (Handshake, default):** You should keep Program Start On until Program End signal turns on. Or an error will occur.
  - **1 (Pulse):** With a rising edge of Program Start Input Pulse, a program keeps running until Program End turns on. If you want to restart the program, start signal should be Off at the end of program.
- **Tare Axes Load After Homing (0:Not Applied/ 1:Only Axis1/ 2:Only Axis2 / 3:Axis1 & Axis2):** Axes load can vary a little bit on the press-installed circumstance like temperature or humidity. If users want to ignore the load variation and see a stable value close to zero, they can use this option.
  - **0 (Not Applied):** You can see the real load values of axes.
  - **1 (Only Axis #1, default):** OACIS tares the load of axis #1 every homing.
  - **2 (Only Axis #2):** OACIS tares the load of axis #2 every homing.
  - **3 (Only Axis #1 & #2):** OACIS tares the load of axis #1 & axis #2 every homing.
- **Fieldbus Config:** This option format is AABB.CCDD.
  - AA: Module Selection (00: EIP, ProfiNet / 01: CC Link)
  - BB: Return Axis Info : It is only for 1XC&2XC not for 1X&2X. If PLC wants to get real-time

OACIS position and load values and displays them on HMI, this option can meet their request. For EIP / PN, FB#45 is StepNo.ErrorCode(Ex. 0013.0601 -> ErrorCode: 601 / StepNo: 13) and for CCLink, FB#45 is ErrorCode.StepNo (Ex. 0601.0013-> ErrorCode: 601 / StepNo: 13).

- . 00: Not Use

- . 01: FB#45: Current StepNo, FB#44: Axis1 Pos, FB#43: Axis1 Load, FB#42: Axis2 Pos, and FB#41: Axis2 Load

- . 02: FB#45: StepNo.ErrorCode

- . 03: FB#45: StepNo.ErrorCode(or ErrorCode.StepNo), FB#44: Axis1 Pos, FB#43: Axis1 Load, FB#42: Axis2 Pos, and FB#41: Axis2 Load

➤ CC: Reserved

➤ DD: Reserved

- **Fieldbus Module Config:** This option is only for CC-Link and the format is AABB.CCDD

➤ AA: Reserved

➤ BB: Reserved

➤ CC: Node No (01, default)

➤ DD: Baud Rate (02, default) It should be the same as CC-Link transmission rate.

Transmission rate/ mode setting switch		Set the module's transmission rate and operation state. (Default setting: 0)	
No.	Transmission rate setting	Mode	
0	Transmission rate 156kbps	On-line	
1	Transmission rate 625kbps		
2	Transmission rate 2.5Mbps		
3	Transmission rate 5Mbps		
4	Transmission rate 10Mbps		
5	Transmission rate 156kbps	Line test	
6	Transmission rate 625kbps	When station NO. setting switch is 0: Line test 1 When station NO. setting switch is 1 to 64: Line test 2	
7	Transmission rate 2.5Mbps		
8	Transmission rate 5Mbps		
9	Transmission rate 10Mbps		
A	Transmission rate 156kbps	Hardware test	
B	Transmission rate 625kbps		
C	Transmission rate 2.5Mbps		
D	Transmission rate 5Mbps		
E	Transmission rate 10Mbps		
F	Setting is inhibited.		

- **Program Execution Time Option:** OACIS can adjust program execution time or delay time from program end to resume with this option.

For example,

➤ **0 (execution time, default):** OACIS adjusts minimum time from program start to resume. When taking option 0 and setting 2 sec as program execution time, it takes 2 sec to resume although cycle time is only 1 sec.

➤ **1 (delay time):** It adjusts delay time from program end to resume. When taking option 1 and setting 2 sec as program execution time, it restarts 2 sec after program end.

- **Homing Option:** When OACIS returns to home in the mode with their own home positions, it can move to system home or program home according to this option. Format of the option is ABCD.EFGH. D stands for Axis #1 and C for Axis #2.

For example,

➤ **0 (system home, default):** If you press "return home" button, the press moves to absolute home and then goes to system home.

➤ **1 (program home):** If you press "return home" button, the press moves to absolute home and then goes to program home.

For example,

➤ 0001.0000 : When homing, finally axis #1 goes to program home and axis #2 goes to system home if there is axis #2.

- Var 41 ~ Var 128: Reserved

**< How to jog the Axis by Hardwire instead of PC Command >**

1. Set the Axis DI Jog Mode as Enable by setting the proper User Configuration #1 parameters as 1. (See above section C.5)
2. Set the proper DI Jog Speed (see above section C.5)
3. Verify hard-wiring of the Programmable Digital Input #5, 6 for OACIS-1X/1XC or DI #11, 12, 13, 14 for OACIS-2X/2XC.
4. DI #11 and #12 will be used to select Axis for OACIS-2X/2XC.
5. DI #5, 6(OACIS-1X/1XC) or DI #13, 14(OACIS-2X/2XC) will be used to move the Axis in positive direction or negative direction.
6. Programmable Digital Input Assignment for DI Jog Mode

OACIS-1X/1XC	JOG COMMAND			
Digital Input #	Stop	Advance	Retract	Stop
5	Off	On	Off	On
6	Off	Off	On	On

OACIS-2X/2XC	AXIS SELECTION			
Digital Input #	Axis 1	Axis 2	Axis 3	Axis 4
11	On	Off	On	Off
12	Off	On	On	Off

JOG COMMAND				
Digital Input #	Stop	Advance	Retract	Stop
13	Off	On	Off	On
14	Off	Off	On	On


Example I: If you want to advance Axis #1 at the speed of 5mm/s for OACIS-1X.

1. Set User Config #1 Parameters as below and save it.

Axis #4 Position Control Error Limit	0
Axis #1 DI Jog Mode Enable (0: Disable / 1:Enable)	1
Axis #2 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #3 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #4 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #1 DI Jog Speed	5
Axis #2 DI Jog Speed	0
Axis #3 DI Jog Speed	0

2. Set Digital Inputs As below.

Digital Input #5



Digital Input #6



Example II: If you want to retract Axis #2 at the speed of 5mm/s for OACIS-2X.

1. Set User Config #1 Parameters as below and save it.


Axis #4 Position Control Error Limit	0
Axis #1 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #2 DI Jog Mode Enable (0: Disable / 1:Enable)	1
Axis #3 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #4 DI Jog Mode Enable (0: Disable / 1:Enable)	0
Axis #1 DI Jog Speed	0
Axis #2 DI Jog Speed	5
Axis #3 DI Jog Speed	0
Axis #4 DI Jog Speed	0

2. Set Digital Inputs As below.

**Digital Input #11**

**Digital Input #12**

**Digital Input #13**



HOW TO CONFIGURE

## V. Debug

: In the Debug tab, the user can perform various diagnostic functions including CHECK HOME Z PULSE, SERIAL COM TEST, UDP COM TEST, DATA MANAGER, and OACIS CFILE BACK UP.

### A. ADMIN STATUS

: The user can click the HOME TO Z PULSE COUNT button to read Z PULSE information for the axis.

### B. SERIAL COM



: You can test “RS232 Communication” with the connected OACIS.

1. Open the RS232 Com Port that connected to the OACIS. You may need to input proper Port Setting Parameters (Baud Rate / Data Bits / Stop Bits / Parity and Port Name)
2. Input the proper protocol that you want to test. Refer to the “Appendix #1” for detailed RS232 Com protocol.
3. Click the “SEND” button.
4. Then you can see the received information at the below text box.

**C. UDP COM**

: You can communicate with OACIS via LAN.

- Before starting the LAN COM TEST, check OffLine in the TOOL menu. Then, the user can see the status bar at the bottom of the OACIScom windows change to **OFFLINE**.




1. You have to check the OffLine on Tool menu before starting LAN COM test and then you can see turning into OFFLINE on the Status Strip at the bottom of OACIScom window.
2. You put your Target OACIS IP Address in IP ADDRESS
3. You can choose one from 2007, 2008, 2009 and 2010.
4. You write down a protocol you want.
5. Sometimes you need a control character like CR and LF.
6. You can send the protocol with this button.
7. Then you can see the received information at the text box below.
8. You can erase all the received information from the text box.

HOW TO CONFIGURE

**D. DATA MANAGER**

: The user can clear or backup OACIS data.


1. Deletes data stored in the OACIS controller.



2. Back up data stored in the OACIS controller to the Local PC.




3. Clicking "BACK UP LOCAL DB" displays the following window. Select the folder to save the data and click OK to save the data in .db file format.



## E. TOOL

: The user can back up files related to OACIS.



1. Select the file(s) to back up.
2. Click "BACK UP CONFIG & PROGRAMS"
3. Chose the save path folder and click OK to complete the backup.

※ **By default, Program, ReportSetting, and configuration files are saved.**

## APPENDIX #1: SERIAL COMMUNICATION EXAMPLE VIA RS232 PORT


**A. <Data Out Mode>**

1. Read IP Address, Subnet Mask, Gateway and Machine ID
  - **Request: ">I" + LF**
  - **Response: "IP;192.168.000.002;SUB;255.255.255.000;GATE;192.168.000.001;MAC;00.08.DC.00.00.00" + CR**
    - IP Address: 192.168.000.002
    - Subnet Mask: 255.255.255.000
    - Gateway: 192.168.000.001
    - Mac ID: 00.08.DC.00.00.00
  
2. Read All Test Result
  - **Request: ">DAA" + LF**
  - **Response: "GV;AA;+0000.0001;+0000.0002;+0000.0003;123456789;" + CR**
    - You may set [Length] as 3 at the System Configuration.
    - +0000.0001: The value of Global Variable #1
    - +0000.0002: The value of Global Variable #2
    - +0000.0003: The value of Global Variable #3
    - 123456789: Scanned Information
  
3. Read All Test Result with Failure Mode and Test Time.
  - **Request: ">DAB" + LF**
  - **Response: "GV;AB;+0000.0001;+0000.0002;+0000.0003;123456789;01;120116010101;" + CR**
    - You may set [Length] as 3 at the System Configuration.
    - +0000.0001: The value of Global Variable #1
    - +0000.0002: The value of Global Variable #2
    - +0000.0003: The value of Global Variable #3
    - 123456789: Scanned Information
    - 01: Failure Mode (Status Binary)
    - 120116010101: Test Time (YYMMDDHHMMSS)
  
4. Read Real-time Results with Failure Mode and Test Time.
  - **Request: ">DAF;001;003;111;" + LF**
    - Read from GV001 to GV003
    - 111: 1 (Barcode) + 1(Failure Mode) + 1(Time). 1 means required, 0 means not required.
    - If you want to read from GV #13 to GV #20 with Barcode without Failure Mode and Time, the request packet is to be ">DAF;013;020;100;" + LF.
  - **Response: "GV;AF;+0000.0001;+0000.0002;+0000.0003;123456789;01;120116010101;" + CR**
    - +0000.0001: The value of Global Variable #1
    - +0000.0002: The value of Global Variable #2
    - +0000.0003: The value of Global Variable #3
    - 123456789: Scanned Information
    - 01: Failure Mode (Status Binary)
    - 120116010101: Test Time (YYMMDDHHMMSS)
  
5. Read Real-time Global Variables Randomly with Floating Point Type.
  - **Request: ">DRD;" + Total Quantity of GVs + ";" + GV No + ";" + GV No + ";" + ... + LF**
    - Read Global Variables in the order that you want.
    - The type of values is floating point.
    - Total Quantity of GVs: The total number of Global Variables to be read. You can read 120 Global Variables at one go. It should be 3 digits such as 005, 022 and 060.

- GV No: You can assign randomly the order of Global Variables. But the number of every GV No should be the same as Total Quantity of GVs.
- **Response: "GV; + Total Quantity of GVs + ";" + GV No + ";" + GV Value + ";" + ... + CR**
  - Ex1. If you want to get GV1, GV2, GV5, GV7 and GV8,
    - ✓ Request: ">DRD;005;01;02;05;07;08;" + LF (0x0A)
    - ✓ Response: "GV;005;01;+0001.0000;02;+0002.0000;05;+0005.0000;07;+0007.0000;08;+0008.0000;" + CR (0x0D)
  - Ex2. If you want to get GV7, GV2, GV80, GV40, GV32 and GV2,
    - ✓ Request: ">DRD;006;07;02;80;40;32;02;" + LF (0x0A)
    - ✓ Response: "GV;006;07;+0007.0000;02;+0002.0000;80;+0080.0000;40;+0040.0000;32;+0032.0000;02;+0002.0000;" + CR (0x0D)
  - Ex3. If you want to get GV101, GV110, GV107, GV19, GV10,
    - ✓ Request: ">DRD;005;a1;b0;a7;19;10;" + LF (0x0A)
    - ✓ Response: "GV;005;a1;+0101.0000;b0;+0110.0000;a7;+0107.0000;19;+0019.0000;10;+0010.0000;" + CR (0x0D)
- 6. Read Real-time Global Variables Randomly with Floating or Fixed Point Type.
  - **Request: ">DRF;" + Total Quantity of GVs + ";" + GV No + ";" + GV No + ";" + ... + LF**
    - DRF protocol is all the same as DRD except for the type of values
    - DRF can choose the type of their values as floating point or fixed point by setting it on drop-down point type menu of RS232 ports in System Config
  - **Response: "GV; + Total Quantity of GVs + ";" + GV No + ";" + GV Value + ";" + ... + CR**
- 7. Read 4 Global Variables from 1<sup>st</sup> Global Variable.
  - **Request: ">D01" + LF**
  - **Response: "GV;01;+0000.0001;+0000.0002;+0000.0003;+0000.0004;" + CR**
    - +0000.0001: The value of Global Variable #1
    - +0000.0002: The value of Global Variable #2
    - +0000.0003: The value of Global Variable #3
    - +0000.0004: The value of Global Variable #4
- 8. Read 4 Global Variables from 2<sup>nd</sup> Global Variable.
  - **Request: ">D02" + LF**
  - **Response: "GV;02;+0000.0002;+0000.0003;+0000.0004;+0000.0005;" + CR**
    - +0000.0002: The value of Global Variable #2
    - +0000.0003: The value of Global Variable #3
    - +0000.0004: The value of Global Variable #4
    - +0000.0005: The value of Global Variable #5
- 9. Read 4 Global Variables from 100<sup>th</sup> Global Variable.
  - **Request: ">Da0" + LF**
  - **Response: "GV;a0;+0000.0100;+0000.0101;+0000.0102+0000.0103;" + CR**
    - +0000.0100: The value of Global Variable #100
    - +0000.0101: The value of Global Variable #101
    - +0000.0102: The value of Global Variable #102
    - +0000.0103: The value of Global Variable #103
- 10. Read 4 Global Variables from 110<sup>th</sup> Global Variable.
  - **Request: ">Db0" + LF**
  - **Response: "GV;b0;+0000.0100;+0000.0101;+0000.0102+0000.0103;" + CR**
    - +0000.0110: The value of Global Variable #110
    - +0000.0111: The value of Global Variable #111
    - +0000.0112: The value of Global Variable #112

- +0000.0113: The value of Global Variable #113
11. Read Scanned Information only (from the Last Cycle Result)
    - **Request: ">DEE" + LF**
    - Response: "GV;EE;123456789;" + CR**
      - 123456789: Scanned Information
  12. Read Scanned Information only (from the Last Scanned)
    - **Request: ">S" + LF**
    - **Response: "SD;123456789;" + CR**
      - 123456789: Scanned Information per configuration.
  13. Read real-time values of Positions, Analog Inputs and Encoders
    - **Request: ">RP1" + LF**
      - The protocol command is consist of a Header(>R) and a Sub Header(P1, P2, A1, A2, E1, E2 and AA)
      - P1: Axis1 Position, P2: Axis2 Position, A1: AI#1, A2: AI#2, E1: EI #01, E2: EI #02
      - AA: All of P1, P2, A1, A2, A3, A4, A5, A6, E1 and E2.
    - **Response: "<RP1;" + Real-time Value + ";" + CR**
      - Ex1. If you want to read the value of analog input #1.
        - ✓ Request: ">RA1" + LF (0x0A).
        - ✓ Response: "<RA1;+0000.0000;" + CR (0x0D).
      - Ex2. If you want to read the value of encoder #2.
        - ✓ Request: ">RE2" + LF (0x0A).
        - ✓ Response: "<RE2;+0000.0000;" + CR (0x0D).
      - Ex3. If you want to read all of them,
        - ✓ Request: ">RAA" + LF (0x0A).
        - ✓ Response:
   
"<RAA;+0000.0001;+0000.0002;+0000.0003;+0000.0004;+0000.0005;+0000.0006;+0000.0007;+0000.0008;+0000.0009;+0000.0010;" + CR (0x0D).
  14. Set GV: You can set the selected Global Variables as the specific value.
    - **Request: ">GV1;" + Length + GV No + ";" + GV Value + ";" + ... + LF**
    - **Response: Same as Request String except for End Terminator (CR)**
      - Ex1. If you want to set GV1 and GV2 as 1 and 2 respectively,
        - ✓ Request: ">GV1;002;01;+0001.0000;02;+0002.0000;" + LF (0x0A).
        - ✓ Response: "<GV1;002;01;+0001.0000;02;+0002.0000;" + CR (0x0D).
      - Ex2. If you want to set GV100 and GV101 as 100 and 101 respectively,
        - ✓ Request: ">GV1;002;a0;+0100.0000;a1;+0101.0000;" + LF (0x0A).
        - ✓ Response: "<GV1;002;a0;+0100.0000;a1;+0101.0000;" + CR (0x0D).
  15. Set Serial Number: You can set the serial number of the part.
    - **Request: ">SN1;" + Serial Number + ";" + LF**
    - **Response: "<SN1;" + CR**
      - Ex1. If you want to set the serial number as "123456789",
        - ✓ Request: ">SN1;123456789;" + LF (0x0A).
        - ✓ Response: "<SN1;" + CR (0x0D).
      - Ex2. If you want to set the serial number as "abcdefg",
        - ✓ Request: ">SN1;abcdefg;" + LF (0x0A).
        - ✓ Response: "<SN1;" + CR (0x0D).

※ **Timing Sequence**



**B. <Scan In Mode>**

1. Example #1 (with [USE FORMAT])
  - Scanned Information: 123456789
  - Configuration Setting
    - Starting Byte No: 0
    - Length: 6
    - Total Length: 9
  - Saved Information: 123456
  - Linked DO turned on.
2. Example #2 (with [USE FORMAT])
  - Scanned Information: 123456789
  - Configuration Setting
    - Starting Byte No: 1
    - Length: 6
    - Total Length: 9
  - Saved Information: 234567
  - Linked DO turned on.
3. Example #3 (with [USE FORMAT])
  - Scanned Information: 123456789
  - Configuration Setting
    - Starting Byte No: 3
    - Length: 6
    - Total Length: 8
  - Saved Information: None (because scanned information is longer than Total Length)
  - Linked DO not be turned on.
4. Example #4 (with [USE FORMAT])
  - Scanned Information: 123456789012
  - Configuration Setting
    - Starting Byte No: 1
    - Length: 6
    - Total Length: 9
  - Saved Information: 234567
  - Linked DO turned on.
5. Example #5 (with [NOT USE FORMAT])
  - Scanned Information: 123456789012
  - Configuration Setting
    - Starting Byte No: N/A
    - Length: N/A
    - Total Length: N/A
  - Saved Information: 123456789012 (Max Allowed Length is 59)
  - Linked DO turned on.

**APPENDIX #2: LAN (UDP) COMMUNICATION EXAMPLE**

- A. You can get the required data through LAN Communication. Protocol for LAN communication is exactly same as RS232 Protocol.**
- B. You have to use UDP protocol (not TCP/IP).**
- C. OACIS UDP server Port Number: 2007 ~2010**
1. The LAN socket to each Port Number is supposed to be set differently.
  2. If you want to connect multi devices to the OACIS, you have to use different port number. Max 4 devices are allowed.
    - a. Socket 1 : Port 2007 = OACIS ↔ OACIScom (Dedicated)
    - b. Socket 2 : Port 2008 = OACIS ↔ Device 1
    - c. Socket 3 : Port 2009 = OACIS ↔ Device 2
    - d. Socket 4 : Port 2010 = OACIS ↔ Device 3
- D. It is strongly recommended that each external device should have a different port number.**  
When 2 or more external devices with the same Port number request communications to OACIS, data omission problems might happen.

## APPENDIX #3: OMRON G SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	Setting for OACIS
<b>Pn02</b>	Control Mode Selection	0 to 6	-	0	<b>2</b>
<b>Pn0B</b>	Operation Switch When Using Absolute Encoder	0 to 2	-	0	<b>1</b>
<b>Pn14</b>	Torque Command Filter Time Constant	0 to 2500	0.01ms	80	<b>0</b>
<b>Pn50</b>	Speed Command Scale	10 to 2000	(r/min)/V	300	<b>500*</b> <b>(or 450)</b>
<b>Pn56</b>	the Speed Limit in Torque Control Mode	-20000 to 20000	r/min	50	<b>5,000**</b> <b>(or 4,500)</b>
<b>Pn5B</b>	Torque Command/Speed Limit Selection	0 or 1	-	0	<b>1</b>
<b>Pn5C</b>	Torque Command Scale	10 to 100	0.1 V/100%	30	<b>34</b>

Note \*: It depends on Servomotor's max speed. 500 for max 5,000 rpm ServoMotor / 450 for max 4,500 rpm Servo Motor

Note \*\*: It depends on Servomotor's max speed. 5,000 for max 5,000 rpm ServoMotor / 4,500 for max 4,500 rpm Servo Motor

**\* You may use default value for the below parameters. But you need to confirm.**

Para. No	Contents	Range	Unit	Default	Setting for OACIS
<b>Pn04</b>	Drive Prohibit Input Selection	0 to 2	-	1	<b>1</b>
<b>Pn44</b>	Encoder Divider Numerator Setting	0 to 32767	-	2500	<b>2,500</b>
<b>Pn45</b>	Encoder Divider Denominator Setting	0 to 32767	-	0	<b>0</b>
<b>Pn5D</b>	Torque Output Direction Switch	0 or 1	-	0	<b>0</b>
<b>Pn5E</b>	No. 1 Torque Limit	0 to 500	%	300	<b>300</b>

Please refer to the below description on how to modify the parameters. Below descriptions were captured from OEM's' manual. You can download the proper manual from ATA or OMRON's website.

<http://atainc.com/en/Support/Download01.html>

### Setting and Checking Parameters

#### ■ Overview

Use the following procedure to set or check parameters.

- Go to Parameter Setting Mode. Press the Data key, and then press the Mode key once.
- Set the parameter number (Pn□□) using the Increment and Decrement keys.
- Display the parameter setting by pressing the Data key.
- Change the parameter setting using the Increment, Decrement, and Shift keys.
- Save the changed setting to memory and return to the parameter number display by pressing the Data key.

## ■ Operating Procedures

### Displaying Parameter Setting Mode

PR02G keys	Front panel keys	Display example	Explanation
			The default display is displayed.
			Press the Data key to display Monitor Mode.
			Press the Mode key to display Parameter Setting Mode.

### Setting the Parameter Number

PR02G keys	Front panel keys	Display example	Explanation
			Set the number of the parameter to be set or checked.

### Displaying Parameter Settings

PR02G keys	Front panel keys	Display example	Explanation
			The parameter number will be displayed.
			Press the Data key. The setting of the parameter will be displayed.

### Changing Parameter Settings

- The following operation is not required if you are only checking a parameter setting.

PR02G keys	Front panel keys	Display example	Explanation
			The present setting will be displayed.
			Use the Shift, Increment, and Decrement keys to change the setting. The Shift key is used to change the digit.

### Saving the New Setting to Memory and Returning to the Parameter Number Display




- The following operation is not required if you are only checking a parameter setting.

PR02G keys	Front panel keys	Display example	Explanation
			Press the Data key. The new parameter setting will be saved and the parameter number will be displayed again.

## Parameter Write Mode

Settings changed in Parameter Setting Mode must be saved to EEPROM. To do so, the following procedure must be performed.

### 1. Saving Changed Settings

Key operation	Display example	Explanation
	EE_SEt	Press the Mode key to display Parameter Write Mode.
	EEP -.	Press the Data key to enter Parameter Write Mode.
	EEP --.	Press the Increment key for 5 s or longer.
	- - - - -.	The bar indicator will increase.
	StARt	Writing will start. (This display will appear only momentarily.)
	Fin,Sh.	This display indicates a normal completion. In addition to the "Finish," either "Reset" or "Error" may be displayed. If "Reset" is displayed, writing has been completed normally, but some of the changed parameters will be enabled only after the power has been turned OFF and ON again. Turn OFF the Servo Drive power supply and then turn it ON again. "Error" is displayed if there is a writing error. Write the data again.

## APPENDIX #4: OMRON G5 SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	SETTING For OACIS
Pn001	<b>Control Mode Selection</b>	0 to 6	-	0	<b>2</b>
	0 : Position control(pulse train command)				
	1 : Speed control(analog command)				
	<b>2 : Torque control(analog command)</b>				
	3 : Mode 1:Position control, Mode 2: Speed control				
	4 : Mode 1 : Position control, Mode 2: Torque control				
	5 : Mode 1: Speed control, Mode 2: Torque control 6 : Fully-closed control				
Pn317	<b>Torque Command/ Speed Limit Selection</b>	0 to 2	-	0	<b>1</b>
	0 : Analog input 1 (TREF1)/Pn321				
	1 : Analog input 2 (TREF2)/Analog input(VLIM) 2 : Analog input 1 (TREF1)/Pn321,Pn322				
Pn013	<b>No. 1 Torque Limit</b>	0 to 500	%	500	<b>300</b>

\* You may use default value for the below parameters. But you need to confirm.

Para. No	Contents	Range	Unit	Default	SETTING For OACIS
Pn011	<b>Encoder Dividing Numerator</b>	1 to 262,144	-	2500	<b>2500</b>
Pn015	<b>Operation Switch when Using Absolute Encoder</b>	0 to 2	-	1	<b>1</b>
	0 : Use as absolute encoder. 1 : Use as incremental encoder. 2 : Use as absolute encoder but ignore multi-rotation counter overflow.				
Pn071	<b>Speed Command/Torque Command Input Overflow Level Setting</b>	0 to 100	0.1V	0	<b>0</b>
	Use this parameter to set the overflow level for Speed Command Input (REF: CN1 pin 14) or Torque Command Input (TREF1: CN1 pin 14) using voltage after offset adjustment. Excessive analog input (alarm code 39) will not be detected if this parameter is set to 0.				
Pn104	<b>Torque Command Filter Time Constant</b>	0 to 2,500	0.01ms	84	-
Pn302	<b>Speed Command Scale</b>	0 to 2,000	(r/min)/V	500	<b>500</b>
Pn319	<b>Torque Command Scale</b>	10 to 100	0.1 V /100%	30	-
Pn320	<b>Torque Output Direction Switch</b>	0 or 1	-	0	<b>0</b>
	0 : Direction of motor torque: The +command indicates the forward direction as viewed from the shaft end. 1 : Direction of motor torque: The +command indicates the reverse direction as viewed from the shaft end.				
Pn321	<b>Speed Limit Value Setting</b>	0 to 20,000	r/min	50	-
Pn503	<b>Encoder Dividing Denominator</b>	0 to 262,144	-	0	<b>0</b>
Pn504	<b>Drive Prohibition Input Selection</b>	0 to 2	-	1	<b>1</b>
	0 : Forward drive prohibition input and reverse drive prohibition input enabled. 1 : Forward drive prohibition input and reverse drive prohibition input disabled. 2 : Forward drive prohibition input and reverse drive prohibition input enable.				

## APPENDIX #5: MITSUBISHI MR-J3-A SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
PA01	<b>Selection of control mode</b>	0000 to 0005	-	0000	<b>0004</b>
	0000 : Position control mode				
	0001 : Position control mode and speed control mode				
	0002 : Speed control mode				
	0003 : Speed control mode and torque control mode				
	<b>0004 : Torque control mode</b>				
PA04	<b>Using Electromagnetic brake interlock (MBR)</b>	0000 to 0001	-	0000	<b>0001</b>
	0 : Output device assigned with parameter No. PD14				
	<b>1 : Electromagnetic brake interlock (MBR)</b>				
PA15	<b>Encoder Output Pulse (Pulse/Revolution)</b>	0 to 2,500	pulse/rev	4,000	<b>12,000</b>
PC12	<b>Analog speed limit maximum speed</b>	1 to 50,000	r/min	0	<b>6,000</b>

HOW TO CONFIGURE

## APPENDIX #6: MITSUBISHI MR-J4-A SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
PA01	<b>Selection of control mode</b>	1000 to 1005	-	1000	<b>1004</b>
	0000 : Position control mode				
	0001 : Position control mode and speed control mode				
	0002 : Speed control mode				
	0003 : Speed control mode and torque control mode				
	<b>0004 : Torque control mode</b>				
	0005 : Torque control mode and position control mode				
PA15	<b>Encoder Output Pulse (Pulse/Revolution)</b>	0 to 4,194,304	pulse/rev	4,000	<b>12,000</b>
PC12	<b>Analog speed limit maximum speed</b>	1 to 50,000	r/min	0	<b>6,000</b>
PD24	<b>Using Electromagnetic brake interlock (MBR)</b>	0000 to 0011	-	0000	<b>0005</b>
	00 : Always Off				
	02 : RD				
	03 : ALM				
	04 : Always Off				
	<b>05 : MBR (Electromagnetic brake interlock)</b>				
	06 : DB				
	07 : VLC				
	08 : WNG				
	09 : BWNG				
	0A : Always Off				
	0B : VLC				
	0C : ZSP				
	0D : MTTR				
0F : Always Off					
10 : Always Off					
11 : Always Off					

## APPENDIX #7: PANASONIC MINAS A5-SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
Pr0.01	<b>Control mode setup</b>	0 to 6	-	0	<b>2</b>
	0 : Position(1 <sup>st</sup> mode)				
	1 : Velocity(1 <sup>st</sup> mode)				
	<b>2 : Torque(1<sup>st</sup> mode)</b>				
	3 : Position(1 <sup>st</sup> mode), Velocity(2 <sup>nd</sup> Mode)				
	4 : Position(1 <sup>st</sup> mode), Torque(2 <sup>nd</sup> Mode)				
	5 : Velocity(1 <sup>st</sup> mode), Torque(2 <sup>nd</sup> Mode)				
6 : Full-closed(1 <sup>st</sup> mode)					
Pr0.11	<b>Output pulse counts per one motor revolution</b>	0 to 262,144	-	2,500	<b>10,000</b>
Pr0.13	<b>1<sup>st</sup> torque limit</b>	0 to 500	%	500	<b>300</b>
Pr3.17	<b>Selection of torque command</b>	0 to 2	-	0	<b>1</b>
	0 : Analog input 1, Parameter value				
	<b>1 : Analog input 2, Analog input 1</b>				
	2 : Analog input 1, Parameter value				


\* You may use default value for the below parameters. But you need to confirm.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
Pr0.15	<b>Absolute encoder setup</b>	0 to 2	-	1	<b>1</b>
Pr3.19	<b>Input gain of Torque Command</b>	10 to 100	0.1 V /100%	30	-
Pr3.20	<b>Torque Output Direction Switch</b>	0 or 1	-	0	<b>0</b>
	0 : Direction of motor torque: The +command indicates the forward direction as viewed from the shaft end. 1 : Direction of motor torque: The +command indicates the reverse direction as viewed from the shaft end.				
Pr5.03	<b>Denominator of pulse output division</b>	0 to 262,144	-	0	<b>0</b>
Pr5.04	<b>Over-travel inhibit input setup</b>	0 to 2	-	1	<b>1</b>
	0 : POT → Inhibit positive direction travel NOT → Inhibit negative direction travel				
	<b>1 : Disable POT, NOT</b>				
	2 : POT or NOT input activates Err38.0 Run-inhibition input protection				

Please refer to the below description on how to modify the parameters. Below descriptions were captured from OEM's manual. You can download the proper manual from ATA or Panasonic's website.

[http://industrial.panasonic.com/ww/e/25000/motor\\_fa\\_e/motor\\_fa\\_e.html](http://industrial.panasonic.com/ww/e/25000/motor_fa_e/motor_fa_e.html)

<b>2</b> Preparation	<b>15. How to Use the Front Panel</b>
	<b>Parameter Setup Mode</b>



HOW TO CONFIGURE

**Note**


- After setting up parameters, return to SELECT mode, referring to structure of each mode (P.2-88).
- Each parameter has a limit in number of places for upper-shifting.

## 2

## Preparation

## 15. How to Use the Front Panel

## EEPROM Writing Mode



- Caution**
1. When writing error occurs, make writing again. If the writing error repeats many times, this might be a failure.
  2. Don't turn off the power during EEPROM writing. Incorrect data might be written. If this happens, set up all of parameters again, and re-write after checking the data.
  3. When the error defined by Err11.0 "Under voltage protection of control power supply" occurs, [Error] is displayed indicating that no writing is made to EEPROM.

## APPENDIX #8: PANASONIC MINAS A6-SERIES SERVO DRIVE SETTING

Note: If you changed Servo Drive due to some reasons without ATA's support, you may need to confirm and modify the settings per the below table before you run any operation of OACIS otherwise you can damage the system.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
Pr0.01	<b>Control mode setup</b>	0 to 6	-	0	<b>2</b>
	0 : Position(1 <sup>st</sup> mode)				
	1 : Velocity(1 <sup>st</sup> mode)				
	<b>2 : Torque(1<sup>st</sup> mode)</b>				
	3 : Position(1 <sup>st</sup> mode), Velocity(2 <sup>nd</sup> Mode)				
	4 : Position(1 <sup>st</sup> mode), Torque(2 <sup>nd</sup> Mode)				
	5 : Velocity(1 <sup>st</sup> mode), Torque(2 <sup>nd</sup> Mode)				
6 : Full-closed(1 <sup>st</sup> mode)					
Pr0.11	<b>Output pulse counts per one motor revolution</b>	1 to 2,097,152	-	2,500	<b>10,000</b>
Pr0.13	<b>1<sup>st</sup> torque limit</b>	0 to 500	-	various per model	<b>300<sup>A</sup></b>
Pr3.02	<b>Input gain of speed command</b>	10 to 2,000	-	500	<b>600<sup>B,C</sup></b>
Pr3.17	<b>Selection of torque command</b>	0 to 2	-	0	<b>1</b>
	0 : Analog input 1, Parameter value				
	<b>1 : Analog input 2, Analog input 1</b> 2 : Analog input 1, Parameter value				

**\*Check subscript\***

- A. Default values vary depending on the model. If not 300, set to 300.
- B. Default values vary depending on motor specifications. If Max. RPM is 5000, set to 500.
- C. Refer to the setting table for Pr3.02 (Input gain of speed command)

Maximum Speed (rpm) by Capacity			
	200~750W	1~3kW	4~5kW
200VAC	6000	5000	4500
400VAC		5500	5000

\* You may use default value for the below parameters. But you need to confirm.

Para. No	Contents	Range	Unit	Default	SETTING for OACIS
Pr0.15	<b>Absolute encoder setup</b>	0 to 2	-	1	<b>1</b>
Pr0.16	<b>External regenerative resistor setup</b>	10 to 100	-	A,B,G,H-frame: 3 C,D,E,F-frame: 0	<b>_D</b>
Pr5.13	<b>Over-speed level setup</b>	0 to 20000	r/Min	0	<b>0</b>

D. Depends on drive specifications (A and B frames do not have a built-in resistor). Set to 1 when using an external regenerative resistor with G and H frame drives.

**REVISION**

v1.00: Engineering Released

v1.30 (Feb. 21, 2011)

- Correct RS232 Protocol (“>D02”: read 4 GV’s from 2<sup>nd</sup> GV / Complying with firmware v1.9 or later)

v1.40 (Feb. 21, 2012)

- Added RS232 Protocol: >DAB / >Da0 / >Db0
- Added LAN Communication Protocol (Appendix #2)
- Added RS232 Port Data Out Mode option (Section #1.E)
- Added OMRON SERVO DRIVE Setting (Appendix #3)

v1.50 (Mar. 07, 2012)

- Added Section III (Admin Configuration)

v1.60 (Apr. 20, 2012)

- Section III, Change OACIS IP Address, Added
- Scan In mode description Updated.

v1.70 (May. 20, 2013)

- Appendix RS232 Protocol “Set GV” and “Set Serial Number” Added.
- Section IV.C, User Config1 Updated.

v1.71 (July. 08, 2013)

- Appendix #4, #5 Added

v1.72 (October. 03, 2013)

- Press (N) Axis type Added

v1.73 (December. 08, 2013)

- Appendix RS232 Protocol “>DAF” Added
- Timing Sequence of Appendix RS232 Protocol in <Data Out Mode> Added
- Move to Position Target Tolerance in User Configuration #1 Added
- Panasonic MINAS A5-SERIES SERVO DRIVE Setting Added

v1.74 (December. 08, 2013)

- Appendix 2.C.1 is Updated

v1.75 (Jan. 24, 2014)

- Start Delimiter, End Delimiter, Time Limit In <RS232 Ports> Added
- Appendix 2.C.1 ~ 3 updated
- Panasonic MINAS A5-SERIES SERVO DRIVE Setting Updated

v1.77 (Feb. 24, 2014)

- Document Format Updated

v1.78 (Jun. 17, 2014)

- Document Format Updated

v1.79 (Oct. 15, 2014)

- “Headers & Footers” Format Updated

v1.80 (Oct. 28, 2014)

- Image Size & Resolution Updated.

v1.81 (Feb. 14, 2015)

- Explanation of “Starting Byte No.” Updated.
- DRD protocol in <APPENDIX #1> Added.

v1.82 (Apr. 11, 2015)

- Image updated. Home Signal Priority and Stop Option Added.

**v1.83 (Jun. 16, 2015)**

- Contents page Revised.

**v1.84 (Jul. 21, 2015)**

- Jog mode for OACIS-1x Added.
- Press(kgf) in Axis Type of System Configuration Added.
- Generic and kgf in AI Unit of System Configuration Added.

**v1.85 (Aug. 18, 2015)**

- Encoder Inputs in System Configuration Updated.

**v1.86 (Oct. 04, 2015)**

- RP1, RP2, RA1, RA2, RE1, RE2 and RAA protocols in <APPENDIX #1> Added.
- Program Execution Time in User Configuration #1 Added.
- Program Start Mode in User Configuration #1 Added.

**v1.87 (Jan. 24, 2016)**

- LAN COM TEST in User Configuration #1 Added
- Downsized "All contents"

**v1.88 (Apr. 29, 2016)**

- Appendix 5 Added

**v1.89 (Jun. 27, 2016)**

- Time Limit in RS232 Ports in I.E Revised

**v1.90 (Aug. 04, 2016)**

- Explanation of User Configuration #1 in IV.A Revised

**v1.91 (Dec. 28, 2016)**

- PD No. of MR-J4-A Series in Appendix #6 Revised

**v1.92 (Apr. 8, 2017)**

- Misspelling in IV Revised

**v1.93(Aug. 24, 2017)**

- Added >DRD in Appendix #1 – Timing sequence

**v1.94(Aug. 10, 2018)**

- PANASONIC MINAS A6-Series in Appendix #8 Added
- Page format Updated

**v1.95(Oct. 15, 2019)**

- How to jog the Axis by Hardwire with OACIS-1XC/2XC in User Configuration #1 updated
- Tare Axes Load After Homing in User Configuration #1 Added
- Appendix RS232 Protocol ">DRD" Updated
- Appendix RS232 Protocol ">DRF" Added
- Fieldbus Config in User Configuration #1 Added
- Fieldbus Module Config in User Configuration #1 Added

**v1.96(Sep. 11, 2020)**

- Program Execution Time Option (#40) in User Configuration #1 Added
- Fieldbus Config Options in User Configuration #1 Added

**v1.97(Feb. 18, 2021)**

- Homing Option (#41) in User Configuration #1 Added

**v1.98(May 12, 2021)**

- Stop Option 2 in User Configuration #1 Added

**v2.01(Jan 12, 2026)**

- OACIScom v5 Updated

**v2.02(Feb 19, 2026)**

- Minor Errors Modified

v2.02(Feb 19, 2026)

- Minor Errors Modified

v05.00.01(Feb 25, 2026)

- Migrated from v2.02 to v05.00.01

V05.00.02(Apr 27, 2026)

- APPENDIX #8: PANASONIC MINAS A6 SERIES SERVO DRIVE SETTING Update